GARMENT GUARD
KEYPAD VERSION

Instructions

<u>Installation and code set</u>
Remove the back cover and the connect battery (9v MN 1604 Alkaline). Replace the cover and enter your 4 digit code number, the alarm will mute after you have pressed the 4th digit. When the visual indicator lights have gone out you can press the # key to activate the alarm.

<u>Merchandising</u>
Press the * key followed by your 4 digit code (you will hear a single "beep" every time a key is pressed followed by a double "beep" on the entry of the 4th digit). You can now connect or disconnect the security cables to the alarm and fasten them to the garments without sounding the alarm (the visual indicator arrows will illuminate briefly). When you have finished merchandising reset alarm by pressing the # key.
You do not need to connect all 16 cables, empty sockets can be left.

<u>Operation</u>
When the alarm is active, if the system is interfered with in any way, e.g. by the removal of the back cover, the following occurs.
The alarm will sound. The 2 large red arrows at the top of the alarm and one or more of the small arrows on the front of the alarm will light up, to indicate which garments have been interfered with.

The Alarm is muted by pressing the * key followed by the 4 digit code. To avoid anybody watching for the code you can press any number of keys before the 4 correct ones. Therefore if your codes number is 1234, all of the following will mute the alarm. *1234, *9999991234, *11234.

The visual indicator arrows will remain illuminated for 10 seconds after the alarm is muted to help identify the item which is at risk.
When you have investigated the cause of the alarm and rectified the problem you can reset the alarm by pressing the # key.

<u>Battery Check</u>

On a regular basis check the battery by pressing the 2 large red arrows. If the battery is ok, they will light up. When you change the battery follow the procedure outlined above to re-input the code number.

Change the code
Disarm the system by pressing the * key followed by the current 4 digit code, disconnect all the cables from the sockets.

Remove the back cover and disconnect the battery, wait for 2 minutes and then follow the installation procedure as above.