

2 Port Alarm

Contents

Adhesive pad
2 Terminators
2 Screws
1 Battery Cover Removal Tool

Instructions

This alarm can protect 1 or 2 items of displayed merchandise.

1. Secure the alarm to a table or wall by means of the adhesive pad or screws. If using the adhesive pad remove centre and attach to the base around the anti-tamper switch. Once the alarm is secure insert the plug from the sensor cable into the socket on the alarm. If only 1 sensor is being used, you must insert the terminator into the other socket of the alarm or the alarm will keep sounding.
2. Attach the sensor cable to the device to be protected and ensure the sensor and displayed merchandise are well connected.
3. Turn the alarm on by holding the remote control 1cm from the infrared receiver and pressing the button. You will hear a long beep and the LED will flash every 10 seconds. The alarm is now active. If using the optional mains power supply the centre LED will be continuously lit when alarm is turned on.
4. If the alarm is triggered it will sound and the corresponding LED for each broken connection will flash.
5. Turn the alarm off by holding the remote control 1cm from the infrared receiver and pressing the button. The alarm will beep 3 times and it is now turned off, this will then allow you to resolve the issue. To reset the alarm repeat step 3.
6. The alarm also features an anti-tamper switch which will cause the alarm to sound and the middle LED to flash if an attempt is made to lift the alarm from its position.

Note: If the battery needs to be changed, press in both rectangular holes (using battery cover removal tool or a flat head screwdriver) on either side of the alarm to release the battery cover.



Unit 5 Fullwood Close, Aldermans Green Industrial Estate, Coventry CV2 2SS
Tel: 024 76603535 Fax: 024 76603636
Website: www.myriadtec.com