

TRIM TRAK ALARM

Instructions

Keyswitch operated Alarm with LED indicator, battery test button and battery low indication.

Operation

The RED adaptor cable plus into the socket at the bottom of the alarm to allow the Trim Trak batten to connect to the alarm, up to 4 of the 6 port battens can be used with the alarm. Plug the accessory cables into the battens and attach the limpet to the products you are protecting using a sticky washer ensuring that the centre of the washers has been removed and the switch is depressed. The key should be turned to set the alarm and removed. The key cannot be removed when the alarm is switched off.

If the alarm sounds insert the key and turn the alarm off. Investigate what has caused the activation and rectify. Sticky washers should only be used once and if they have been removed they must be replaced. When resolved, reset the alarm by turning and removing the key.

Battery – test/change

Pressing the test button on the front of the alarm will illuminate the LED unless the battery is flat. If you hold the button down for 3 seconds the sounder will activate. When the battery is running low the alarm will “beep” and flash the LED periodically.

To change the battery turn the alarm off and remove the RED cable, slide open the battery compartment cover and remove the battery. Replace the battery with a 9 volt alkaline mn1604 (PP3).

DIMENSIONS – 140mm x 90 x 44

**MYRIAD**
TECHNOLOGIES LIMITED

Unit 5 Fullwood Close, Aldermans Green Industrial Estate, Coventry CV2 2SS

Tel: 024 76603535 Fax: 024 76603636

Website: www.myriadtec.com

